

FREQUENTLY ORDERED REPLACEMENTS

PALISADE & PALM BAY - SLING

ORIGINAL MODEL NAME	PALISADE ORIGINAL MODEL NUMBER	PALM BAY ORIGINAL MODEL NUMBER	SLING REPLACEMENT #	PADDED SLING REPLACEMENT # (PERIMETER STITCH)
Standard Back Dining Chair	7E370	73370/75470	73390S	76591S
Standard Back Swivel Rocker	7E360	75360	73390S	76591S
High Back Dining Chair	7E379	73379	73900S	76900S
High Back Swivel Rocker	7E910	75910	73900S	76900S
Swivel Balcony Stool	7E580	75580	73390S	76591S
Swivel Rocker Balcony Stool	7E780	75780	73390S	76591S
Bar Stool	7E480	75280/75480	73390S	76591S
Standard Back Loveseat Glider	N/A	75450	73390S - Order 2	76591S - Order 2
High Back Loveseat Glider	7E459	75459	73900S - Order 2	76900S - Order 2
Self-Adjusting Chaise - Square Corner Bottom	N/A	73300	73300S	N/A
Self-Adjusting Chaise - Round Corner Bottom	7E301	73301	7E300S	7E201S
Ottoman	73120	73120	73120S	76120S

PALISADE & PALM BAY/CHESHER BAY - PADDED SLING

ORIGINAL MODEL NAME	PALISADE ORIGINAL MODEL NUMBER	PALM BAY/CHESHER BAY ORIGINAL MODEL NUMBER	PADDED SLING REPLACEMENT # (PERIMETER STITCH)	SLING REPLACEMENT #
Standard Back Dining Chair	7E470	75371/75370	76591S	73390S
Standard Back Swivel Rocker	7E390	75390	76591S	73390S
Standard Back Dining Spring Chair	N/A	75230	76591S	73390S
High Back Dining Chair	7E479	75379	76900S	73900S
High Back Swivel Rocker	7E900	75900	76900S	73900S
High Back Dining Spring Chair	N/A	75490	76900S	73900S
Bar Stool	7E290/7E490	75290/75490	76591S	73390S
Standard Back Loveseat Glider	N/A	75440	76591S - Order 2	73390S - Order 2
High Back Loveseat Glider	7E429	75449	76900S - Order 2	73900S - Order 2
Recliner	N/A	75500	N/A	73500S
Self-Adjusting Chaise - Square Corner Bottom	N/A	75300	N/A	73300S
Self-Adjusting Chaise - Round Corner Bottom	7E201	75301	7E201S	7E300S
Adjustable Chaise	N/A	75400	N/A	73400S
Spring Base Chaise	N/A	75310	N/A	73310S
Swivel Rocking Chaise	N/A	75690	N/A	73690S
Ottoman	75120	75120	76120S	73120S

FREQUENTLY ORDERED REPLACEMENTS

HOLLY HILL - SLING

Note: External Cross-Bar was before 2008 - Internal Cross-Bar from after 2008. *Order wood tool 402151.

ORIGINAL MODEL NAME	ORIGINAL MODEL NUMBER	SLING REPLACEMENT #	PADDED SLING REPLACEMENT # (PERIMETER STITCH)
High Back Swivel Rocker - External Cross-Bar	2A900	73900S	76900S
High Back Swivel Rocker - Internal Cross-Bar	2A900	7390RS	76910S
High Back Dining Chair - External Cross-Bar	2A379/2A579	73900S	76900S
High Back Dining Chair - Internal Cross-Bar	2A379/2A579	7390RS	76910S
Standard Back Swivel Rocker - External Cross-Bar	2A360	73390S	76591S
Standard Back Swivel Rocker - Internal Cross-Bar	2A360	7339RS	76590S
Standard Back Dining Chair - External Cross-Bar	2A370	73390S	76591S
Standard Back Dining Chair - Internal Cross-Bar	2A370	7339RS	76590S
Swivel Balcony Stool - External Cross-Bar	2A580	73390S	76591S
Swivel Balcony Stool - Internal Cross-Bar	2A580	7339RS	76590S
Swivel Rocker Balcony Stool - External Cross-Bar	2A780	73390S	76591S
Swivel Rocker Balcony Stool - Internal Cross-Bar	2A780	7339RS	76590S
Bar Stool	2A240/2A280	73390S	76591S
Bar Stool - External Cross-Bar	2A480	73390S	76591S
Bar Stool - Internal Cross-Bar	2A480	7339RS	76590S
Standard Back Loveseat Glider - External Cross-Bar	2A440	73390S - Order 2	76591S - Order 2
High Back Loveseat Glider - External Cross-Bar	2A449	73900S - Order 2	76900S - Order 2
High Back Loveseat Glider - Internal Cross-Bar	2A449	7390RS - Order 2	76910S - Order 2
Self-Adjusting Chaise - External Cross-Bar	2A300	3J300S	7610RS
Self-Adjusting Chaise - Internal Cross-Bar	2A300	3J30RS	7610RS
Adjustable Chaise - External Cross-Bar*	2A400	2A400S	N/A
Ottoman - External Cross-Bar	2A120	73120S	76120S

FREQUENTLY ORDERED REPLACEMENTS

HOLLY HILL - PADDED SLING

Note: External Cross-Bar was before 2008 - Internal Cross-Bar from after 2008. *Order wood tool 402151.

ORIGINAL MODEL NAME	ORIGINAL MODEL NUMBER	PADDED SLING REPLACEMENT # (PERIMETER STITCH)	SLING REPLACEMENT #
Standard Back Dining Chair - External Cross-Bar	2A470	76591S	73390S
Standard Back Dining Chair - Internal Cross-Bar	2A470	76590S	7339RS
Standard Back Swivel Rocker - External Cross-Bar	2A390	76591S	73390S
Standard Back Swivel Rocker - Internal Cross-Bar	2A390	76590S	7339RS
High Back Dining Chair - External Cross-Bar	2A479	76900S	73900S
High Back Dining Chair - Internal Cross-Bar	2A479	76910S	7390RS
High Back Swivel Rocker - External Cross-Bar	2A910	76900S	73900S
High Back Swivel Rocker - Internal Cross-Bar	2A910	76910S	7390RS
Swivel Balcony Stool - External Cross-Bar	2A590	76591S	73390S
Swivel Balcony Stool - Internal Cross-Bar	2A590	76590S	7339RS
Swivel Rocker Balcony Stool - External Cross-Bar	2A790	76591S	73390S
Swivel Rocker Balcony Stool - Internal Cross-Bar	2A790	76590S	7339RS
Bar Stool	2A250/2A290	76591S	73390S
Bar Stool - External Cross-Bar	2A270	76591S	73390S
Bar Stool - Internal Cross-Bar	2A270	76590S	7339RS
Standard Back Loveseat Glider - External Cross-Bar	2A450	76591S - Order 2	73390S - Order 2
High Back Loveseat Glider - External Cross-Bar	2A459	76900S - Order 2	73900S - Order 2
High Back Loveseat Glider - Internal Cross-Bar	2A459	76910S - Order 2	7390RS - Order 2
Self-Adjusting Chaise - External Cross-Bar	2A100	7610RS	3J300S
Self-Adjusting Chaise - Internal Cross-Bar	2A100	7610RS	3J30RS
Adjustable Chaise - External Cross-Bar*	2A200	N/A	2A400S
Ottoman - External Cross-Bar	2A130	76120S	73120S

FREQUENTLY ORDERED REPLACEMENTS

KENSINGTON I & KENSINGTON II - SLING

ORIGINAL MODEL NAME	KENSINGTON I ORIGINAL MODEL NUMBER	KENSINGTON II ORIGINAL MODEL NUMBER	SLING REPLACEMENT #	PADDED SLING REPLACEMENT # (PERIMETER STITCH)
Standard Back Dining Chair	N/A	40470	73390S	76591S
Standard Back Swivel Rocker	N/A	40360	73390S	76591S
Mid Back Dining Chair	40370	N/A	40900S	N/A
Mid Back Swivel Rocker	40900	N/A	40900S	N/A
High Back Dining Chair	N/A	40379	73900S	76900S
High Back Swivel Rocker	N/A	40909	73900S	76900S
Swivel Balcony Stool	N/A	40580	73390S	76591S
Swivel Rocker Balcony Stool	N/A	40780	73390S	76591S
Bar Stool	N/A	40280/40480	73390S	76591S
Standard Back Loveseat Glider	N/A	40450	73390S - Order 2	76591S - Order 2
Mid Back Loveseat Glider	40440	N/A	40900S - Order 2	N/A
High Back Loveseat Glider	N/A	40449	73900S - Order 2	76900S - Order 2
Adjustable Chaise	40400	40400	40400S	N/A
Ottoman	40120	40120	73120S	76120S

KENSINGTON I & KENSINGTON II - PADDED SLING

ORIGINAL MODEL NAME	KENSINGTON I ORIGINAL MODEL NUMBER	KENSINGTON II ORIGINAL MODEL NUMBER	PADDED SLING REPLACEMENT # (PERIMETER STITCH)	SLING REPLACEMENT #
Standard Back Dining Chair	N/A	40470	76591S	73390S
Standard Back Swivel Rocker	N/A	40360	76591S	73390S
Mid Back Dining Chair	40370	N/A	N/A	40900S
Mid Back Swivel Rocker	40900	N/A	N/A	40900S
High Back Dining Chair	N/A	40379	76900S	73900S
High Back Swivel Rocker	N/A	40909	76900S	73900S
Swivel Balcony Stool	N/A	40580	76591S	73390S
Swivel Rocker Balcony Stool	N/A	40780	76591S	73390S
Bar Stool	N/A	40280/40480	76591S	73390S
Standard Back Loveseat Glider	N/A	40450	76591S - Order 2	73390S - Order 2
Mid Back Loveseat Glider	40440	N/A	N/A	40900S - Order 2
High Back Loveseat Glider	N/A	40449	76900S - Order 2	73900S - Order 2
Adjustable Chaise	40400	40400	N/A	40400S
Ottoman	40120	40120	76120S	73120S